



## " Charge light Function "

For PowerGen Number that ends in "-2"

Due to the Variation on Vehicle Wirings, a specific Wiring Diagram cannot be Provided with this unit. Please refer to Your Vehicle Wiring Diagram to locate the Dash "Gen Light" wire, Disconnect that wire from the Generator or Regulator and Connect it to the PowerGen Dash Light Terminal

"This is an internal regulated unit"

The **existing** external **regulator** on vehicle must be **disconnected**

